

Product Parts


- 1 - Left Frame Assembly
- 2 - Right Frame Assembly
- 3 - Top Horizontal Pole
- 4 - Bottom Horizontal Pole
- 5 - Graphic
- 6 - Carrying Case



Display Set-Up


Step 1

Remove the parts from the bag and place on a clean, flat surface, along with your banner. Lay the Left Frame Assembly (1) on its side and unfold and push the poles down into the joints as shown. Repeat step for Right Frame Assembly (2).



Step 2

Stand the Left Frame Assembly (1) upright and fold open and push the Vertical poles down into the joints as shown. Repeat step for Right Frame Assembly (2).




Step 3

Insert Top Horizontal Pole (3) into the Left Frame Assembly (1) by matching up the labels on the hardware. Push in the push-button and insert as shown. Repeat step for Bottom Pole (4).



Step 4

Slide the Graphic (5) on the Top and Bottom Horizontal Poles (3 & 4) as shown. Continue to slide the graphic until the Horizontal Poles are exposed on the opposite end.



Step 5

Connect the Right Frame Assembly (2) to the Top Horizontal Pole (3) as shown. Repeat step for Bottom Horizontal Pole (4).



Step 6

To adjust the height, open the telescoping clamp as shown.



Display Set-Up Continued...


Step 7

Center the Graphic on the unit and with two people, begin to raise the top vertical poles upward until the graphic is taught to the frame as shown.

** Vertical poles are not meant to exceed product height of 94.125"*

Step 8

Snap the telescoping clamps closed to secure poles.



To Adjust the Width

To adjust the width, locate the Blue "A" and "B" Labels on the Left Frame Assembly (1). Push in the push-button and slide pole to desired setting.

*"A" - Setting for the 10' Bravo Graphic
(Do Not exceed 10' width setting)*

*"B" - Setting for the 8' Bravo Graphic
(Frame will go narrower than this setting
without the use of the push-button)*



Storage & Care

Place all product parts into Carry Case (6) and store in a cool dry location. Machine wash cold, gentle cycle. Air Dry Only. DO NOT Dry Clean!

